
12AX7A OR 7025 PREAMPLIFIER V1
12AU7A MIXER PHASE-INVERTER REVERB PWR. AMP V4
12AX7A OR 7025 REVERB AMPLIFIER V5
12DW7/7247 MIXER DRIVER PHASE INVERTER V6
(2) 6CA7/EL34 POWER AMPLIFIER V7, V8
12AX7A OR 7025 PREAMPLIFIER V2
12DW7 TREMOLO MODULATOR V3B
HIGH GAIN
NORMAL CHANNEL
LOW GAIN
TREMOLO CHANNEL
T1 25K: 8.5Ω
T2 5500Ω 4Ω
25-0008 DELAY LINE
FOOT SWITCH
EXTERNAL SPEAKER
MP-3 TWO (2) 16Ω SPEAKERS
MP-5 TWO (2) 16Ω SPEAKERS
RECORDING NORMAL SOUND LEVEL
POWER SWITCH
OFF
STANDBY
OU (ANTI-HUM 1)
OU (ANTI-HUM 2)
117V 60CPS 180 WATTS
3A SLO-BLO
140V
220V
340V
400V
T3
6.3V AC FILAMENTS
500K DIMMER
PANEL LIGHTS
NEON LAMP TREMOLO OSCILLATOR AND INDICATOR
½ 12DW7 LAMP DRIVER V3A
TREMOLO INTENSITY
TREMOLO SPEED
TREMOLO FOOT SWITCH
SWITCH OPENS AT MIN. INTENSITY
G.E. #669 INCANDESCENT
WARNING NOTE
DO NOT APPLY TEST PROBES, OR OTHERWISE CONTACT THIS GRID, AS TUBE CURRENT SURGE MAY BURN OUT LAMP.
MUSICAL INSTRUMENT AMPLIFIER
MODELS MP-3 AND MP-5
66-3124
POWER TRANSFORMER T3
OUTPUT TRANSFORMER T2
REVERB TRANSFORMER T1
NOTES
1. HIGH VOLTAGE RECTIFIERS 600 PIV, 600MA
2. VOLTAGES READ WITH VOM, NO AUDIO SIGNAL, ALL CONTROLS TO "OFF" POSITION 117VOLT LINE.
3. UNLESS OTHERWISE INDICATED,
a. ALL CAPACITANCES IN MICROFARADS, 400 VOLT, 10% TOLERANCE.
b. ALL RESISTANCE IN OHMS, ½ WATT, 10% TOLERANCE.
REELS & DECKS
A ECN 2115
B ECN 2117
C ECN 2118
D ECN 2132
E 2172 8-1-66
B.C. 10-65
ESTEY TORRANCE, CALIFORNIA
MUSICAL INSTRUMENT AMP.
MODEL MP-3 or MP-5
66-3124
D
E

25.%

13